p 4.			Builtioreepae	
1	day, 7/16/2007 2:44:44 PM Johnston	oce Shoot		-31
	Proce	ess Sheet	· .	
Customer	: CU-DAR001 Dart Helicopters Services	Drawing Name	: FLOAT SKIDTUBE	
Job Number	: 33555			
	: 10366			
Estimate Number		Part Number	: D412742013	
P.O. Number	: ALA	•	: N/A	
This Issue	: 7/16/2007 S.O. No. : NA	Drawing Number	•	
Prsht Rev.	: NC	Project Number	: N/A	
First Issue	: NIA Type : LANDING GEAR	Drawing Revision	: N/A	
Previous Run	: 33526	Material	: MA	
Written By	· · · · / /	Due Date	: 7/30/2007 Qty:	1 Um: Each
	9 Lo 7 07, 17	, <b>*</b>		
Checked & Approv	: Est Rev: A 05.10.13 New Issue KJ/JLM			, -
Comment				
	Est Rev.B 06-06-08 As per DSI9336 JLM			
Additional Produc	<u> </u>			
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,				
	*			
Job Number:	EMPLOY MATERIAL MATERIAL PROPERTY			
JOD HUITIDGE.				•
1.				
Seq. #:	Machine Or Operation:	Description :		
1.0	DC DOCUME	NT CONTROL		
1.0				
Comm	ent: DOCUMENT CONTROL			3
	Photocopy bluefile and create labels per PPP D412-	742-013 CHG003	Ep 07/08/8	2/
2.0		KID ASSEMBLY		
2.0		(ID //OOLWIDE)		
Comm	ent: Sub-Component FLOAT SKID ASSEMBLY	1 )		
	D412-742-043 B 33548A	2/8/21	59	
20	, , , , ,			
3.0	D2571 Saddle, Fr	wa, Out	, (1 <b>481</b> 1)1 <b>88</b> 11 <b>148</b> 1	
<b>]</b> .				
Comm	ent: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Ea	ich(s)		
]	Pick:	·-··\=/		
		1		
	Qty Part Number Description Batch	01.1		
~	1 D2571 Saddle Fwd Outside	<u> </u>	34	
	•	_	<i>,</i>	
4.0	D2572 Saddle, Fo	wd, In		
7.0		•	~ 1 HÅNK BNI 1811	
			<b>∮∥∭∥№</b>	
	_			
Commo	ent: Qty.: 1.0000 Each(s)/Unit Total : 1.0000 Ea	ch(s)		
	Pick:			
7.7	Qty Part Number Description Batch,	, /	54	
I ~ .		<i>f</i> . <i>[</i>	<b>3</b> *	
		<u> </u>		
5.0	D2573 Saddle, Af	rt, Out	1 (801)+ BB11 1881	
			] [ <b>[]</b> [] <b>[</b> [] [] [] [] [] [] [] [] [] [] [] [] []	
-Comme	ent: Qty.: 1.0000 Each(s)/Unit Total : 1.0000 Ea	ch(s)	1100111 10111 1011	
l Comme	•	U1(0)		
\ \frac{1}{2}	Pick:	1	1 1	
	Qty Part Number Description Batch	21	2/7/24 50	0
	1 D2573 Saddle Aft Outside / 53/f/-	<b>∠</b> Y	71 F/ WY 34	

Monday, 7/16/2007 2:44:44 PM Date: User: Kim Johnston **Process Sheet** Customer: CU-DAR001 Dart Helicopters Services Drawing Name: FLOAT SKIDTUBE Job Number: 33555 Part Number: D412742013 .Job Number: Description: Machine Or Operation: Seq. #: Saddle, Aft, In D2574 6.0 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Comment: Qty.: Pick: **Qty Part Number** Description Batch Saddle Aft Outside 1 D2574 7.0 Comment: Qty.: 4.0000 Each(s)/Unit Total: 4.0000 Each(s) Pick: Description 531300 Qty Part Number 4 D2747 8.0 D2876 Saddle Spacer Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s) Pick: **Qty Part Number** Description 2 D2876 Saddle Spacer 9.0 D2877 Saddle Spacer Comment: Qty.: Total: 2.0000 Each(s) 2.0000 Each(s)/Unit Pick: **Qty Part Number** Description 2 D2877 Saddle Spacer D34031 10.0 Comment: Qty.: 16.0000 Each(s)/Unit Total: 16.0000 Each(s) B33562VS0 Pick: **Qty Part Number** 16 D3403-1 11.0 D34033 Bushing Comment: Qty.: 8.0000 Each(s)/Unit Total: 8.0000 Each(s) Pick: Description **Qty Part Number** 8 D3403-3 Bushing

Date: Monday, 7/16/2007 2:44:44 PM Kim Johnston Ùser: **Process Sheet** Drawing Name: FLOAT SKIDTUBE Customer: CU-DAR001 Dart Helicopters Services Job Number: 33555 Part Number: D412742013 . Job Number: Description: Seq. #: Machine Or Operation: Lug Assembly 12.0 D3405041 1.0000 Each(s) Comment: Qty.: 1.0000 Each(s)/Unit Total: Pick: Qty Part Number Description Batch 1 D3405-041 **GHW** Lug D3405043 13.0 Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Pick: 59 **Qty Part Number** Description 1 D3405-043 GHW Lug 14.0 AN4C6A Comment: Qty.: 16.0000 Each(s)/Unit Total: 16.0000 Each(s) Pick: 59 Qty Part Number Description 16 AN4C6A Bolt AN4C46A 15.0 Comment: Qty.: 4.0000 Each(s)/Unit Total: 4.0000 Each(s) Pick: Description **Qty Part Number** Bolt AN4C46A AN4C52A 16.0 Comment: Qtv.: 8.0000 Each(s)/Unit Total: 8.0000 Each(s) Pick: SP **Qty Part Number** Description AN4C52A Bolt 17.0 AN6C12A Comment: Qty.: 8.0000 Each(s)/Unit Total: 8.0000 Each(s) Pick: 7/7/2459 **Qty Part Number** Description 8 AN6C12A

<sup>c</sup> Monday, 7/16/2007 2:44:44 PM Date: User: Kim Johnston **Process Sheet** Drawing Name: FLOAT SKIDTUBE Customer: CU-DAR001 Dart Helicopters Services Job Number: 33555 Part Number: D412742013 Job Number: Description: Seq. #: Machine Or Operation: WASHER 18.0 AN960C416L 32.0000 Each(s)/Unit Total: 32.0000 Each(s) Comment: Qty.: 50 Pick: Description Batch
Washer <u>M.10 9,16</u> **Qty Part Number** +/ 32 AN960C416L WASHER 19.0 AN960C616L 8.0000 Each(s) Comment: Qty.: 8.0000 Each(s)/Unit Total: Pick: Description Batch Washer <u>M18922</u> Qty Part Number 59 +) 8 AN960C616L AN960C716L WASHER 20.0 Comment: Qty.: 16.0000 Each(s)/Unit Total: 16.0000 Each(s) Pick: Description Qty Part Number 16 AN960C716L Washer A Nut MS210434 21.0 Comment: Qty.: 29.0000 Each(s)/Unit Total: 29.0000 Each(s) Qty Part Number Description Batch
29 MS21043-4Nut M/04931 22.0 NAS1515H4L Inventory Comment: Qty.: 32.0000 Each(s)/Unit Total: 32.0000 Each(s) Pick: Description Batch
Washer MI04956 Qty Part Number 2/2/24 59 *├*/ 32 NAS1515H4L

Monday, 7/16/2007 2:44:44 PM Date: Kim Johnston User: **Process Sheet** Customer: CU-DAR001 Dart Helicopters Services Drawing Name: FLOAT SKIDTUBE Job Number: 33555 Part Number: D412742013 . Job Number: Description: Seq. #: **Machine Or Operation:** 23.0 NAS1515H6L Inventory 8.0000 Each(s) Comment: Qty.: 8.0000 Each(s)/Unit Total: Pick: vescription Batch Washer M 18918 Description Qty Part Number 8 NAS1515H6L NAS1515H7L Inventory 24.0 Comment: Qty.: 16.0000 Each(s)/Unit Total: 16.0000 Each(s) M100727 / SP Pick: Description **Qty Part Number** Washer 16 NAS1515H7L D3407041 Tow Ring 25.0 Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s) Pick: **Qty Part Number** Description 1 D3407-041 **TOW RING** D34173 26.0 Comment: Qty.: 2.0000 Each(s)/Unit Total: 2.0000 Each(s) Pick: **Qty Part Number** Description Batch 35/9 U 2 D3417-3 WASHER 27.0 D34561 Comment: Qty.: 1.0000 Each(s) 1.0000 Each(s)/Unit Total: Pick: Description **Qty Part Number** WASHER D3456-1 AN4C7A 28.0 Comment: Qty.: 4.0000 Each(s) 4.0000 Each(s)/Unit Total: Bolt M1171427

Date: Monday, 7/16/2007 2:44:44 PM User: Kim Johnston **Process Sheet** Drawing Name: FLOAT SKIDTUBE Customer: CU-DAR001 Dart Helicopters Services Job Number: 33555 Part Number: D412742013 - Job Number: Description: Seq. #: Machine Or Operation: INSPECT 100% KITS FOR COMPLETENESS 29.0 QC4 100% KITS FOR COMPLETENESS Comment: INSPECT 30.0 Comment: PACKAGING RESOURCE #1 Identify and pack for shipping as per PPP D412-7, Location: 31.0 Comment: FINAL INSPECTION/W/O RELEASE Job Completion U 07.08.22

1.0000 Each(s)/Unit Total: 1.0000 Each(s)

Pick:

Qty Part Number

1 D2572

Saddle Fwd Inside

Description Batch

D2573

5.0

Saddle, Aft, Out



1.0000 Each(s)/Unit Comment: Qty.:

1 D2573

1.0000 Each(s) Total :

Batch

Pick:

Qty Part Number Description

Saddle Aft Outside

Page 1

i.		,	Dart Aerospa	ace Ltd.
Date: Monday, 7/16/20	007 2:44:58 PM		<del></del>	— <u>7</u>
User: Kim Johnston	Proce	ess Sheet		
Čustomer : CU-l	DAR001 Dart Helicopters Services	Drawing Name	: FLOAT SKID ASSEMBLY	
Job Number : 3355				
Estimate Number : 1075 P.O. Number : 1075		Part Number	: D412742043	
This Issue : 7/16	/ 1 4	Drawing Number	: D3391 REV F	
Prsht Rev. : NC First Issue : M	Type : LANDING GEAR	Project Number Drawing Revision	: N/A : F	
First Issue : /// Previous Run : 3352	Type : LANDING GEAR 26A	Material	MM	
Written By	:	Due Date	: 7/30/2007 <b>Qty</b> :	1 Um: Each
Checked & Approved By	: _ 9,107,07,17			
Comment	: Est Rev A 65.10.13 New Issue Est Rev B 06.02.13 ECN 773 dwg @ rev.D	KJ/JLM EC		
•	Est Rev:C 07-05-28 As per Rev F	· JLM		
Additional Product				
Job Number:				
	1			
	hine Or Operation:	Description :		
1.0 DC	TIMMINA IIMIIMIIIMI	INT CONTROL		•
				·
Comment: DO	CUMENT CONTROL		March on 3558	
	412-742-043 is a W/O on it's own,		Ly Cary Do Sign	
	otocopy bluefile and create labels per PPP D412-		A C	
2.0 D33910	023 Mid Tube	Assembly	1   <b>[ [ ] ]   1   1   1   1   1   1   1   1   1</b>	
·				
Comment: Qty		ich(s)		
pick			1	
Qty 1	Part Number Description Batch D3391-023 Mid Tube Assembly	31946		
3.0 D33910				
4				
	1			
Comment: Qty	• •	ich(s)		
pick Qty		<b>a</b>		
: 1	D3391-025 Aft Tube Assembly B 3	1858	21	
		<u> </u>	12	
4.0 D35641	WEARSH	OE	1 1881 17 88 71 1881	

Comment: Qty.: 1.0000 Each(s)/Unit Total: 1.0000 Each(s)

WEARSHOE
Batch: 33243 47 01

41 01-07-29

Monday, 7/16/2007 2:44:58 PM Date: User: Kim Johnston **Process Sheet** Drawing Name: FLOAT SKID ASSEMBLY Customer: CU-DAR001 Dart Helicopters Services Job Number: 33555A Part Number: D412742043 Job Number: Description: Seq. #: **Machine Or Operation:** WEARSHOE D35643 5.0 1.0000 Each(s) Comment: Qty.: 1.0000 Each(s)/Unit 4 B3376 **WEARSHOE** LT 07.03-729 1.0000 Each(s) Comment: Qty.: 1.0000 Each(s)/Unit Total: **WEARSHOE** Batch: 32778 2 07-07-29 Comment: Qty.: 2.0000 Each(s) 2.0000 Each(s)/Unit Total: **GASKET** 33458 25 07 07-29 Batch: 1.0000 Each(s) Comment: Qty.: 1.0000 Each(s)/Unit Total: **GASKET** 9.0 AN3C4A Comment: Qty.: 24.0000 Each(s)/Unit Total: 24.0000 Each(s) **BOLT** 104945 Batch: AN3C6A 10.0 Total: 12.0000 Each(s) Comment: Qty.: 12.0000 Each(s)/Unit **BOLT** 07-67-29 03693 Batch: 11.0 AN3C7A Comment: Qty.: 8.0000 Each(s)/Unit Total: 8.0000 Each(s) **BOLT** 103668 0707 29 Batch:

Monday, 7/16/2007 2:44:58 PM Date: Kim Johnston User: **Process Sheet Drawing Name: FLOAT SKID ASSEMBLY** Customer: CU-DAR001 Dart Helicopters Services Job Number: 33555A Part Number: D412742043 Job Number: Description : Seq. #: Machine Or Operation: AN960C10L washer 12.0 44.0000 Each(s) Comment: Qty.: 44.0000 Each(s)/Unit Total: washer 64 64 29 Batch: 13.0 Comment: HAND FINISHING RESOURCE #1 2-Install tubes together and seal them all the way around using Sikaflex 241/291. Ensure tube ends line-up with saddle holes for proper alignment, using 7/16" "T" Pins. 21 07-07 19 Sikaflex-241/-291 **104989** Expiry date: 1-0% 3-Install wearplates as per Dwg D3391. Ensure that plastic washers are against wearplate, then topped with the SS washer. Coat bolts with LPS "procyon". Seal all bolts with sikaflex exept ones with inserts on inside of tube ,hand tighten only bolts with no sikaflex.

A/R LPS Procyon (100) (100) (100) Sikaflex-241/-291 /DY989 A/R 01-01-08 Expiry date: 4-Remove "T" pins once sikaflex is dry. 5-Coat all exposed hardware with LPS Procyon. Remove any excess off with MEK degreaser. QC5 INSPECT WORK TO CURRENT STEP 14.0 WORK TO CURRENT STEP PACKAGING RESOURCE #1 15.0 Comment: PACKAGING RESOURCE #1 Identify and pack for shipping as per PPP D412-742-043 Location: PPP B33=25 PPP Rev:

Date:

Monday, 7/16/2007 2:44:58 PM

User:

Kim Johnston

**Process Sheet** 

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: FLOAT SKID ASSEMBLY

Job Number: 33555A

Part Number: D412742043

Job Number:



Seq. #:

Machine Or Operation:

Description:

16.0

QC21

FINAL INSPECTION/W/O RELEASE





Comment: FINAL INSPECTION/W/O RELEASE

Job Completion



1 St. 04-30









